

Pioneer DMH-WT8600NEX

Monitor size:

10-1/8 inches (width) x 5-3/4 inches (height) x 1-1/2 inches (depth)
257mm (width) x 147mm (height) x 37mm (depth)

PRINTING INSTRUCTIONS (use of the latest version of Adobe® Acrobat® Reader® or Acrobat Pro software is recommended)

This image represents actual product size when printed in Actual size on US letter size paper.

1. Choose File > Print.
2. Within the **Paper Sizing & Handling** section, choose **Actual size**.
3. In the Document preview pane, confirm the Document size is 11.0 x 8.5in.
4. Click the **Print** button.
5. To check printing size accuracy, use a ruler or measuring tape. The outside dimensions of this image should match the measurements shown above.
6. Cut out this image to use as a template to check the size of the DMH-WT8600NEX monitor in your vehicle.

Read the important display mounting **⚠ WARNING** on page 12 of the **Installation Manual**.

The DMH-WT8600NEX monitor can be configured in multiple horizontal, vertical and angled positions. See pages 12 - 17 of the **Installation Manual** for details. pioneerelectronics.com/PUSA/Car/NEX/DMH-WT8600NEX#manuals

Ensure that the monitor will not obstruct the driver's clear view of the road, impair the performance of any of the vehicle's operating system or safety features including airbags, indicators (lights) and hazard lamp buttons, or impair the driver's ability to safely operate the vehicle.

Pioneer

